


Source: Leece-Neville Heavy Duty Systems Division - Arcade, NY USA  
 Date: July 7, 2017  
 Bulletin No: TSB-1044  
 Models: 8LHA2094VA, 8LHA2071VA (110-555IJHO)  
 Subject: Wiring instructions to replace 8LHA2094VA with 8LHA2071VA (110-555IJHO)

**These instructions provide proper wiring connections required to replace the 8LHA-2094VA with an 8LHA2071VA (110-555IJHO).**

The 8LHA2094VA is equipped with a remote voltage sense connection as well as a lamp connection. The 8LHA2071VA (110-555IJHO) is a direct replacement, however, it does not incorporate a remote voltage sense connection point nor a lamp connection point.


When installing the 8LHA2071VA (110-555IJHO) as a direct replacement Positive Battery (B+) and Negative Battery (B-) connections are required. Remote voltage sense is not required and the alternator will function normally. There is no provision for a lamp connection and the dash lamp will no longer be operable.

**(8LHA2094VA)**



**8LHA2071VA (110-555IJHO)**

**These wiring instructions are applicable to all 110-555 series part numbers with any suffix.**



Important: The information contained in this bulletin is intended for use by trained, professional technicians who have the proper tools, equipment, and training to perform the required maintenance described above. This information is NOT intended for 'do-it-yourselfers'; and you should not assume that this information applies to your equipment. If you have any questions regarding this information please visit our website at [www.prestolite.com](http://www.prestolite.com), or contact our technical service department at: